

# *1 Channel Mixer Rehearser*

*Pietango.com*

1



**GAIN**

-20 dB

+ 48v





**PAN**

L - R



WE CANT HEAR ANY SOUND!



1


**GAIN**

-20 dB

+ 48v


**PAN**

L - R




THE SOUND IS ONLY ON ONE SIDE!

*Previous page: The LR assign button wasn't pressed.*



L R



1



**GAIN**

-20 dB

+ 48v





**PAN**

L - R



WE CANT HEAR ANY SOUND!

*Previous page: It was panned to the right.*



1



**GAIN**

-20 dB

+ 48v





**PAN**

L - R



WE CANT HEAR ANY SOUND!

*Previous page: The gain was too low.*



1



**GAIN**

-20 dB

+ 48v





**PAN**

L - R



WE CANT HEAR ANY SOUND!

*Previous page: Phantom power +48 was needed.*





**GAIN**

**-20 dB**

**+ 48v**




**PAN**

**L - R**



THE VOLUME IS TOO LOW!

*Previous page: The channel fader was down.*



1



**GAIN**

-20 dB

+ 48v





**PAN**

L - R



THE SOUND IS ONLY ON ONE SIDE!

*Previous page: The -20 pad was pressed.*





1



**GAIN**

-20 dB

+ 48v




**PAN**

L - R



WE CANT HEAR ANY SOUND!  
*Previous page: It was panned to the left.*



1



**GAIN**

-20 dB

+ 48v




**PAN**

L - R




PEAK LIGHT IS ALWAYS ON!

*Previous page: The master fader was down.*



L

R





**GAIN**

-20 dB

+ 48v




**PAN**

L - R



LEVEL METERS ARE TOO HIGH!

*Previous page: The gain was too high.*



**L**

**R**



1

**GAIN**

-20 dB


+ 48v

**PAN**

L - R



*Previous page: LR master faders are too high.*



**L**

**R**

