



# *Fold-Back Rehearser*

*Pietango.com*

Send less Piano to the Singer please.




The Piano has asked for less Vocals.




*Answer to Previous: Turn down Piano Aux3*

The Drummer can't hear the Singer.




*Answer to Previous: Turn down Vocals Aux4*

Send more Guitar to the Guitarist.




*Answer to Previous: Turn up Vocals Aux1*

The Bass just asked for less Guitar.




*Answer to Previous: Turn up Guitar Aux5*

Could you send more Drums to the Bass Player.



*Answer to Previous: Turn down Guitar Aux2*


The Drummer asked for less Piano in his Fold-back.



*Answer to Previous: Turn up Drums Aux2*




The Guitar needs to hear more Bass.




*Answer to Previous: Turn down Piano Aux1*

The Singer is singing off-key, try sending her more Vocals.




*Answer to Previous: Turn up Bass Aux5*

Our Pianist is asking for more Bass.




*Answer to Previous: Turn up Vocals Aux3*

Send more Vocals to the Bass Player please.




*Answer to Previous: Turn up Bass Aux4*

Please turn up the Drums in the Drummer's Fold-back.




*Answer to Previous: Turn up Vocals Aux2*

The Singer is signalling less Drums in her Floor Monitor please.




*Answer to Previous: Turn up Drums Aux1*

Send less Vocals to the Guitarist please.



*Answer to Previous: Turn down Drums Aux3*


Could you turn up the Bass in the Singer's Floor Monitor.



*Answer to Previous: Turn down Vocals Aux5*




The Pianist can't hear the Piano, more Piano please.




*Answer to Previous: Turn up Bass Aux3*

Send less Bass to the Drummer.




*Answer to Previous: Turn up Piano Aux4*

The Guitarist cant hear the Piano.




*Answer to Previous: Turn down Bass Aux1*

The Guitarist needs less Drums please.




*Answer to Previous: Turn up Piano Aux5*

The Bass cant hear enough Bass.



*Answer to Previous: Turn down Drums Aux5*



*Answer to Previous: Turn up Bass Aux2*